
| SEIKAKU TECHNICAL GROUP LIMITED | | | | | | | | |
|---------------------------------|---|---------|-------------|--------|--|-------|---------------------------|--|
| 客 | 户 | | | | | | | |
| 料 | 號 | NF01870 | | | | | | |
| D D | 名 | CSL-8XX | 系列 雨無言 | 新_V1.0 | | | | |
| 規 | 格 | 説明書 | 英文 | | | | | |
| 材 | 質 | 105克雙 | 銅紙 | | | | | |
| 紙張展開性質 | | A3 A4 | A5 <u>其</u> | Te . | | 紙張展開數 | 量 1張 | |
| 核准 | | 審查 | χ. | 校稿 | | 製稿 | 研發部 NOV.21.2005 黄國奇 | |
| 產品文件編號: | | | | | | | | |

備注: 依制六課要求重新出圖,附陽片.


CEILING SPEAKER

Installation Procedures:


1. Drill a round hole into the ceiling in accordance with the ceiling-drilling picture on the attached cover in the inner box.



2. Choose required input voltage and output power for equipment connecting set-up. Detailed specifications can be referred as the instruction on the speaker itself and the following product specifications.



3. After simultaneously pressing the fixed springs on both sides of the ceiling speaker to the end push it into the round hole of the ceiling and then the speaker is fixed.



^ Caution: Wrong voltage input set-up might cause damage of the speaker.

| Model | Ceiling Speaker 6W | Ceiling Speaker 10W | | |
|---------------------------------------|--|--|--|--|
| Paper Speaker Inside | 1×8" full-range paper speaker | 1×8" full-range paper speaker | | |
| Input Power | Standard 6W | Standard 10W | | |
| Output Power | 6W/3W/1.5W | 10W/5W/2.5W | | |
| Input Resistance | (100V): 6.6KΩ 3.3KΩ 1.66KΩ (70V): 3.3KΩ 1.66KΩ 816Ω | (100V): 4KΩ 2KΩ 1KΩ (70V): 2KΩ 1KΩ 490Ω | | |
| Input Voltage | 70V/100V | 70V/100V | | |
| Frequency | 140~20,000 Hz | 140~20,000 Hz | | |
| Output Sound Pressure & Voltage | 95 dB(1W/M) | 95 dB(1W/M) | | |
| Dimension | Φ265×74.5 mm / 10.4×2.9" | Φ265×78.5 mm / 10.4×3.1" | | |
| Weight | 1.1Kg / 2.42LB | 1.2Kg / 2.64LB | | |